

WHAT TOU WILL HEED







Polycap









Captive Nut Assembly

Caulking Tool



Hole **Connector**



Silicone Caulk



Plastic Sheet



Melamine





Hopper Gun



Paste Mold Release



Tape



Face Mix



Molding Clay





Backer Mix


Drill holes into the sink mold for the <u>Captive Nut Assembly</u> and the <u>Overflow Hole Connector</u>




Create a sink mold out of melamine




Attach the <u>Polydome</u> to the <u>Polycap</u>, insert the <u>Captive</u> <u>Nut Assembly</u>, and screw it onto your sink mold.











Put molding clay on the bottom of your sink mold to keep it in place while applying silicone






Apply <u>paste</u> release to anything you will caulk


Remove excess <u>paste</u>
with a paper towel to
remove streaks and
imperfections on your
surface


Apply <u>caulk</u> to any edge you want to round off












Apply tape to the Polydome, and the hole in the Polycap

THE POLYDONE IS REUSING BLEE





Shake and pour the Precast Modifier and the Face Mix into a bucket

The Precast Modifier increases the strength, adhesion, retains moisture, has fast set additives, and much more! No water required!



Mix the <u>Face Mix</u> with an electric mixer in an industrial bucket

Scrape the sides of your bucket and mix again



Pour the <u>Face Mix</u> into your <u>hopper gun</u>, set the nozzle size to ¼ inch, and the air pressure to 40 PSI

Be sure to test the spray before using the hopper gun on your mold!



Spray the <u>Face</u>
<u>Mix</u> on your
entire mold.
Make sure to
cover
everything!



Fix any imperfections by tapping them with a <u>brush</u>



Once the face coat does not stick to your finger, spray the second coat

Waiting too long will prevent the two coats from bonding




Cut the <u>Overflow Tube</u> to your desired length, and attach it to your <u>Polycap</u>

CUT SMOLL
UCISIONS ON THE
SIDE OF THE TUBE TO
USENT OT ENSIEN


Once the second coat doesn't stick to your finger, mix the Backer Mix



Be sure to shake your precast modifier before pouring it!



Apply
Backer Mix
at % of an inch



Form your drop edge, and cover the mold with plastic overnight





