







Top-Coat



Epoxy Pigment



Mix Bucket



Floor Grinder



Flakes



Self Leveling Concrete



Painters Tape



Plastic Sheet



<u>Squeegee</u>





Epoxy Roller





Spike Shoes



BEFORE WE STORT



Make sure your floor is completely flat and level. This can be achieved with a floor grinder or self leveling concrete.





Make sure Vour concrete hasno moisture!

Tape a 2'X2' sheet of plastic to the floor and leave overnight. If there is water under the plastic, your concrete is retaining moisture





Squeegee the epoxy onto your floor

(Coverage- 90-100 sq. feet at 16-18 mils) 5








Roll your <u>EpoxyGlide</u> Roller on painters tape to remove loose fibers



EpoxyGlide Rollers are made specifically for sticky materials like epoxy

Backroll the <u>epoxy</u> to get an even spread across your finnr





Throw the <u>flakes</u> into the air and let them fall onto your <u>epoxy</u>

Chicken Feeding



your pattern, and also get slip resistance!



Cover wet spots with more flakes

Try to maintain an even spread of flakes on your floor



Once the <u>epoxy</u> dries, (usually 12-24 hours) vacuum the extra <u>flakes</u> off







topcoat and roll it with an **EpoxyGlide**



topcoats are super durable!



Watch the Full Video Here!

